

Current USA
Replacement Part Detail Report



How to read this chart:

1. Identify the model number light fixture you have. Model numbers can be found on the product packaging and within the serial number of your unit. The serial number is located on the back of the light fixture with the model number being identified as follows:
2. Locate the replacement item required by its description in the second column. The Replacement Part Number for this item can be found next to it in the "Replacement Part #" column.
3. The columns on the right indicate how many of the specific part(s) is used in your model. Please be sure to only order the quantity you require.

How to obtain parts for products not under warranty:

If your product is no longer under warranty and you require a replacement part, we recommend first contacting your local retailer. Many local retailers stock our replacement parts or can obtain one for you quickly. In addition, replacement parts can be purchased online through many online web retailers.

How to obtain parts for products under warranty:

Current-USA products carry a one year limited warranty from the date of purchase, lamps carry a 3-month limited warranty. If your product is within warranty and you require a replacement part, they can be obtained by either:

1. Contacting your local retailer and requesting a replacement part under warranty. Many dealers are able to get common replacement parts quickly for warranty service.
2. If your retailer is unable to help you, please fill out the information below and include a copy of your original purchase receipt to **1-760-727-7066**.

Name:
 Mailing Address:
 Phone Number:
 Email Address:
 Serial Number of Fixture:
 Replacement Part Number Required:

Original retailer item was purchased from:

** Please remember to include a copy of your original purchase receipt.

Upon receiving the above complete information, a warranty replacement part will be sent to you. Please allow 7-10 days for delivery.

Replacement Part #	Description: Outer Orbit 150 250 T5HO	Fixture Model #1070	Fixture Model #1071	Fixture Model #1072	Fixture Model #1073	Fixture Model #1074	Fixture Model #1075	Fixture Model #1076	Fixture Model #1077	Fixture Model #1078	Fixture Model #1079
1789	Docking Mounts for Outer Orbits	1	1	1	1	1	1	1	1	1	1
1907	Ballast 150 watt (no enclosure)	1	2	2	2	3					
1908	HQI Reflector	1	2	2	2	3	1	2	2	2	3
1909	HQI Socket	1	2	2	2	3					
1912	HQI Glass Cover	1	2	2	2	3	1	2	2	2	3
1930	HO Surface Mount Sockets / Pair	4	4	4	4	8	4	4	4	4	8
1953	250w HQI Socket Model 1056 1075-1079 and 1160-1166						1	2	2	2	3
1747	On/Off Rocker Switch	4	4	4	4	4	3	3	3	3	3
1929	6-LED Panel 3 Blue 3 White	2	3	3	3	4	2	3	3	3	4
1940	Lunar Light Transformer with Connector 300 MA	2	2	2	2	2	2	2	2	2	2
1952	(1) 1x250 watt ballast assembly						1	2	2	2	3
1745	3"x1" Replacement Fan	1	1	2	2	3	1	1	2	2	3